

LA1 ☒

LA5 ☐

LA10 ☐

LA14 ☐

LA24 ☐

FA14 ☐

IA14 ☐

black

white

red

1.5 mm²

0 Ω between white and red when fully retracted.

Stroke	R
1 – 2"	940 Ω/cm
3 – 4"	470 Ω/cm
5 – 6"	315 Ω/cm

min. stroke = 0 Ω

Ω = R × cm

POTENTIOMETER DATA	
Max. power:	1.5 W
Resistance tolerance:	± 5 %
Resistance linearity:	± 0.25 %

LA1 ☐

LA5 ☒

LA10 ☒

LA14 ☒

LA24 ☒

FA14 ☒

IA14 ☐

grey

yellow

green

1.5 mm²

0 Ω between yellow and grey when fully extended.

Stroke	R
0 – 10"	390 Ω/cm
11 – 20"	200 Ω/cm
21 – 40"	100 Ω/cm

Ω = R × cm

max. stroke = 0 Ω

POTENTIOMETER DATA	
Max. power:	2 W
Resistance tolerance:	± 5 %
Resistance linearity:	± 0.25 %

LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☒

LA24 ☒

FA14 ☒

IA14 ☒

Magnet position with extension
tube fully retracted

L1

Magnet position with extension
tube fully extended

L2

Actuator type	Actuator designation	L1 (mm)	L2 (mm)
LA14, LA24, FA14	xAxx-xxAxx	32	35
LA14, LA24, FA14, IA14	xAxx-xxBxx	92	20

The reed switch sensors should normally be placed about 25 mm before these position in order to compensate for the distance needed for deceleration.



LA1 ☒
 LA5 ☐
 LA10 ☐
 LA14 ☐
 LA24 ☐
 FA14 ☐
 IA14 ☐

If using a LA1 actuator with integrated end stroke limit switches (designation Sxx-xxAxx-xxxx), make sure to switch off the power to the motor if the extension tube can not extend or retract fully. Otherwise the motor will keep running which may cause damage to the actuator.

Always turn power off before working on the actuator or the wiring.

[illegible]

Tollo Linear AB PRINTED IN SWEDEN © 1994 dw110206-gb-0528
Box 9053, SE-291 09 Kristianstad, Sweden rev. 10
Tel. +46 (0)44-246700, Fax +46 (0)44-244085 Printed on recycled paper



Basic mounting rules

LA1 ☒

LA5 ☒


LA10 ☒

LA14 ☒

LA24 ☒

FA14 ☒

IA14 ☒



LA1 ☒

LA5 ☒


LA10 ☒

LA14 ☒

LA24 ☒

FA14 ☒

IA14 ☒



LA1 ☒

LA5 ☒


LA10 ☒

LA14 ☒

LA24 ☒

FA14 ☒

IA14 ☒



LA1 ☒

LA5 ☒

LA10 ☒

LA14 ☒

LA24 ☒


FA14 ☒

IA14 ☒

Restraining torque

Torque needed to prevent extension tube from rotating.

LA1	2.3 Nm
LA5	11.3 Nm
LA10	11.3 Nm



LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☒

LA24 ☒


FA14 ☒

IA14 ☐

Only mount actuator in these points!

* Trunnion (option), p/no. D603 022 (2x)

Correct tightening torque = 4.4 Nm.



LA1 ☒

LA5 ☒

LA10 ☒

LA14 ☒


LA24 ☒

FA14 ☒

IA14 ☒

Only use solid pins!

LA1	LA 1	LA5, LA10
LA5	ø = 6.35 mm	ø = 12.7 mm
LA10	p/no. D603 034 (2x)	p/no. D603 028 (2x)
LA14	LA14, LA24, FA14, IA14	
LA24	ø = 12 mm	
FA14	p/no. D603 023 (2x)	
IA14		



LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☒


LA24 ☒

FA14 ☒

IA14 ☒

Trunnion holders (option)

p/no. D603 030 (2x)



LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☒


LA24 ☒

FA14 ☒

IA14 ☒

Pin holders (option)

p/no. D603 029 (2x)



Basic mounting rules

LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☐

LA24 ☐


FA14 ☒

IA14 ☒

Only mount actuator in these points!

Foot mount (standard)

* Trunnion (option) p/no: D603 022 (2x)



LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☐


LA24 ☐

FA14 ☒

IA14 ☒

Motor flange

Drill hole and make key way in the coupling to fit your motor shaft. The coupling accepts holes between ø10 – 19 mm.



Wire cross section

LA1 ☒

LA5 ☐

LA10 ☐

LA14 ☐

LA24 ☐


FA14 ☐

IA14 ☐

12 VDC

24 VDC

36 VDC



LA1 ☐

LA5 ☒

LA10 ☐

LA14 ☐

LA24 ☒


FA14 ☐

IA14 ☐

115 VAC

230 VAC

400 VAC



LA1 ☐

LA5 ☐

LA10 ☒

LA14 ☒

LA24 ☐


FA14 ☐

IA14 ☐

12 VDC

24 VDC

36 VDC



12 VDC				24 VDC			36 VDC	
Current (A)	mm ²			Current (A)	mm ²		Current (A)	mm ²
	L = 3 m	L = 6 m	L = 10 m		L = 6 m	L = 10 m		L = 10 m
0 – 15	1.5	2.5	4	0 – 10	1.5	1.5	0 – 12	1.5
16 – 20	2.5	4	6	11 – 15	2.5	2.5		
21 – 28	4	6	10					
29 – 34	6	6	10					

The tables are based on ambient temperature = 30°C or less.

Connection of motor

LA1 ☒

LA5 ☐


LA10 ☐

LA14 ☐

LA24 ☐

FA14 ☐

IA14 ☐



LA1 ☐

LA5 ☐


LA10 ☒

LA14 ☒

LA24 ☐

FA14 ☐

IA14 ☐



LA1 ☐

LA5 ☒

LA10 ☐


LA14 ☐

LA24 ☒

FA14 ☐

IA14 ☐

230 and 115 Vac supply without brake (A22-xxxx-xxxxNxxxx, AA22-xxxxxMxxxxNxxxx)



LA1 ☐

LA5 ☐

LA10 ☐


LA14 ☐

LA24 ☒

FA14 ☐

IA14 ☐

230 and 115 Vac supply with brake (A22-xxxx-xxxxBxxxx, AA22-xxxxxMxxxxBxxxx)



LA1 ☐

LA5 ☐

LA10 ☐


LA14 ☐

LA24 ☒

FA14 ☐

IA14 ☐

3 x 400 Vac supply without brake (A42-xxxxxMxxxxNxxxx, AA42-xxxxxMxxxxNxxxx)



LA1 ☐

LA5 ☐

LA10 ☐

LA14 ☐

LA24 ☒

FA14 ☐

IA14 ☐

3 x 400 Vac supply with brake (A42-xxxxxMxxxxBxxxx, AA42-xxxxxMxxxxBxxxx)

